

# INTRALOT PHOTON TERMINAL SET UP INSTRUCTIONS

## TRAINING MODE

Once your Photon Terminal has been installed, you may use the training mode at any time to familiarize yourself and your team with the device. In the **TERMINAL TAB**, press the **TRAINING MODE** button. Confirm your selection. Press the **SIGN IN** button and enter in the last 6 digits of the retailer number for the user ID and 9999 for the passcode. To exit training mode, simply press the **SIGN OFF** button and confirm your selection.

## THE COMPLETE PHOTON FAMILY



From left to right: Genion, Accelerated Modem, Photon Terminal, Barcode Reader, Printer, and Player Advertisement Display

## EQUIPMENT LIST

### Photon Terminal Package

1. Photon Terminal (1 pcs)
2. BRC Case Holder (1 pcs)
3. 2D Barcode Scanner (1 pcs)
4. Light Proof Shield (2 pcs)
5. Photon AC Cord (1 pcs)
6. Photon Adapter 12V 12.5A (1 pcs)

### Accelerated Modem Package

1. Accelerated Modem (1pcs)
2. Modem Power Cable
3. LAN Cable for LAN Port 1

### Printer TSP-L10 Package

1. Printer TSP-L10 (1 pcs)
2. Printer Power Cable (1 pcs)
3. Printer Power Supply Adaptor (1 pcs)
4. USB Cable (1 pcs)

### Genion Package


1. Genion Lite (1 pcs)
2. Genion Power Cable (1 pcs)
3. Genion Power Supply Adaptor (1 pcs)
4. LAN Cable for LAN Port 2

### Player Advertisement Display (PAD)


1. Power Cable
2. HDMI Cable

## CABLES AND POWER CORDS

### Photon Terminal AC Cord and Adaptor




### Genion Power Cable and Adaptor




**CABLES AND POWER CORDS**


**Printer Power Cable and Adaptor**



Printer Power Cable




Printer Power Supply Adaptor




Printer USB Cable

**LAN Cable (2pcs) for Accelerated Modem and Genion**



**PAD HDMI CABLE**



**PHOTON TERMINAL CONNECTION DIAGRAM**


Player Advertisement Display



Printer



Keypad



Photon Rear Panel

Barcode Scanner



TP Link Switch



Wireless Modem



Genion Ticket Checker

